

aune

XP2 High-Quality Upgrade Power Supply

User Manual


# Preface

Dear Customers:

Thanks for purchasing the aune XP2 and congratulations on choosing this high-quality upgrade power supply. We sincerely hope the XP2 will bring you excellent Hi-Fi experience.

Please read this manual carefully before using the device.

## Front / Rear Panel at a Glance



1.1 Indicator light

2.1 AC Power input

2.2 Power switch

2.3 DC output (for aune X1s GT/ X8/ XC1/ X5s/ X1s Pro/ Flamingo-BD )

2.4 DC output (for aune X1s GT/ X8/ XC1/ X5s/ X1s Pro/ Flamingo-BD )

## Introduction

The XP2 is a high-quality upgrade power supply for the aune X1s GT/ X8/ XC1/ X5s/ X1s Pro/ Flamingo-BD.

## Specifications

Output voltage: DC 9V/1A,

for aune X1s GT/ X8/ XC1/ X5s/ X1s Pro/ Flamingo-BD

Accessories: AC Power cord\*1 / DC to DC cable\*2

Fuse: 1A

Dimensions: 131mm x 85mm x 60mm

Weight: 1kg



Caution: Before using the product, please make sure that the voltage in your area matches the voltage indicated on the product label.

# Operations

Connect the XP2 to a supported device via the output cable, insert the power cord and switch on the power.

Note: A maximum of two devices can be connected to one XP2.

XP2 Rear Panel



aune

aune | 430034WUHAN | CHINA

Email: [sales@auneaudio.com](mailto:sales@auneaudio.com) | Fax: +86-27-85840435 | [www.auneaudio.com](http://www.auneaudio.com)